






5,2
 t/h*


276 x 210
 AxB mm


210
 Ø max.* mm




 Diesel + Avviamento elettrico
 Diesel + Electric start
 Diesel + Démarreur électrique
 Dieselmotor + Elektroanlasser
 Diesel + Arranque eléctrico
 Diesel + Elektrische start
 Diesel + Elektrické startování
 Dizel + Elektro start
 Diesel + Rozruch elektryczny
 Diesel + Электростартом


 Trainato da trattore
 Towed by tractor
 Remorqué par tracteur
 Geschleppt vom Traktor
 Remolcado por tractor
 Geslept door tractor
 Vuče sa traktorom
 Traktorski
 Zaciągnikowy
 Букируется Трактором


 Portato da trattore
 Three-point linkage for tractor
 Attelage trois-points pour tracteur
 Dreipunkt-Anschluss für Traktor
 Enganche tres puntos para tractor
 Driepunt bevestiging
 Veza s tri točke za traktor
 Priključak u tri točke
 3-punktowy układ zawieszania
 Сцепка трехточечнаяЭлектростартом


 KOHLER KDI1903TCR
 hp56



L L/h
30 9,6

					OBS					
	C21DL560TRGN		KOHLER KDI1903TCR hp56	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	5,2	4480/4995 x 1600 x 2450/3220	760	1350 x 840	1650/
	C21DL560TRON		KOHLER KDI1903TCR hp56	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	5,2	4480/4995 x 1600 x 2450/3220	760	1350 x 840	1650/
	C21DL56CN		KOHLER KDI1903TCR hp56	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	5,2	2980/3500 x 1650 x 2450/3220	760	1350 x 840	2090/
	C21TTN		Min. hp60 (kW44)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	5,2	3420/3420 x 1750 x 2450/3220	760	1350 x 840	1090/
	C21TPN		Min. hp60 (kW44)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	5,2	2310/2830 x 1650 x 2450/3220	760	1350 x 840	1120/

***** Materiale in entrata - Dato dipendente dal tipo di materiale e dalle condizioni di lavoro. / Input material - Data depending on the kind of material and working conditions. / Matière entrante - Donnée dépendante du type de matériel et des conditions de travail. / Eingangsmaterial - Daten, die von der Art des Materials und den Arbeitsbedingungen abhängen. / Material entrante - Dato que depende del tipo de material y de las condiciones de trabajo. / Ingangsmateriaal - Deze gegevens zijn afhankelijk van het soort materiaal en de werkomstandigheden. / Vstupní materiál em - Záleží na druhu materiálu a pracovních podmínkách. / Ulazni materijal - Ovisno o vrsti materijala i uvjetima rada. / Material wśadowy - W zależności od rodzaju materiału i warunków eksploatacji. / Входной материал - Это зависит от вида материала и от условий труда

